







Congratulations on your new Hegel reference amplifier. The P30A preamplifier and the H30A power amplifier represent the spearhead of our amplifier technology.

We have nicknamed the P30A The Conductor because that is what it is. Its job is to conduct the power amplifier as precisely as possible and to feed that amplifier with a signal that is as true to the music as possible. To achieve this, we use single pair FET transistors, a dead quiet volume control, very short signal paths, and our Sound Engine technology. This makes the P30A sounds very smooth and natural, without compromising on the details. It is a truly brilliant conductor of all music.

The H30A we nicknamed The Orchestra. Its job is to take command of any music on any speakers and make it sound as good as possible without breaking a sweat. And we can think of no more challenging music than a large orchestral piece. The H30A is an absolute powerhouse of an amplifier. In its mono state it delivers a truly astounding 1100 watts in 8 ohms, and it is stable even with 1-ohm loads. It is an amplifier can drive basically all known loudspeakers with authority and ease. It never sounds forced, only relaxed and musical. It is the large orchestra that brings life to any music in any venue.


We hope you enjoy.

Bent Holter

Founder Hegel Music System

Index


A word from Bent	2
What's in the box	4
P30A	6
Connections	7
Remote Control	9
H30A	10
Connections	11
Stereo mode	12
Mono mode	13
Technical Spesifications	14
General Information	15




What's in the box

Preamplifier Power Cord Accessory Box Remote Control User Manual

H30A





Operating the P30A

The source and volume can be changed using the input and volume selector on the front panel or using the remote control.

Power Button

The P30A preamplifier can be switched on and off with the power button located in the middle of the front panel.

NOTE: When powering up, the P30A takes about 60 seconds to calibrate, the outputs are muted and the power light flashes to indicate that mute is on. This is normal and is part of the start-up procedure. When the power light stops flashing the P30A is ready to use.

NOTE: When the P30A has been switched off, wait 30 seconds before powering it on again.

Inputs

The P30A has both unbalanced (RCA) and balanced (XLR) analog inputs. If you have a source with fully balanced outputs, we recommend using balanced cables to connect the source to the P30A.

Outputs

The P30A has both unbalanced (RCA) and balanced (XLR) analog outputs. If you have a power amplifier with fully balanced inputs, we recommend using balanced cables to connect the P30A to the power amplifier.


Control Output

The control/trigger output uses a regular 3,5 mm jack plug. The control output will function with most control/trigger inputs (5-12V) from other manufacturers, but is only guaranteed to work with HEGEL control inputs.

IR Direct Input

This input can be used to connect to an external IR receiver or home automation system.

Connections



Always power off the preamplifier before connecting input/output audio cables and the power cable.

AC Power Connection

 AC Power connector: 230V/115V/100V AC depending on country

IR Direct Input

Input for IR Receiver cable (3,5 mm jack)

Control output

12V control/trigger output (3,5mm jack)

Analog Outputs

- XLR: Variable balanced analog output
- · RCA: Variable unbalanced analog output

NOTE: The RCA 2 output can be configured to work as a fixed analog output. Please contact your Hegel dealer for more information.

NOTE: All outputs are allways active, allowing you to connect several products simultaniously.

Analog Inputs

- 1 (XLR): Standard balanced analog input
- 2 (XLR): Standard balanced analog input
- 3 (RCA): Standard analog input
- 4 (RCA): Standard analog input
- 5 (RCA): Standard analog input
- HT: Home Theatre Max level input


WARNING:

The Home Theatre input uses a fixed high volume level. To prevent damage to your system and your hearing, only connect sources with its own volume controll.

NOTE: The Home Theatere input can be configured to work as a standard analog input. Please contact your Hegel dealer for more information.

NOTE: XLR Pin Configuration: Pin 1 is Chassis Ground; Pin 2 is Positive Phase; Pin 3 is Negative Phase





Remote control buttons (starting top left)

1. PREV Skip to previous track on most media players 2. PLAY Play/Pause on most media players 3. NEXT Skip to next track on most media players 4. DAC+ Input source selector button for Hegel DACs 5. ECO Sets device in low power mode 6. DISP Display on/off (hold for off) 7. PREV Skip to previous track on Hegel CD-players 8. PLAY Play/Pause for Hegel CD-players 9. NEXT Skip to next track on Hegel CD-players 10. IN+ Switches to next input on Hegel amplifiers STOP Stop/Eject for Hegel CD-players 12. VOL+ Volume up for Hegel amplifiers 13. IN-Switches to previous input on Hegel amplifiers 14. MUTE Mute for Hegel amplifiers VOL: Volume down for Hegel amplifiers


General information

The Hegel amplifier can be controlled with the included Hegel RC8 Remote Control. The RC8 controls Hegel products, such as amplifiers and preamplifiers, and most media players, avoiding the need for multiple remote controls.

Batteries

The remote control uses two standard 1.5-volt LR03 AAA batteries. To insert the batteries, use a crosshead (Phillips) screwdriver to remove the back lid,

CAUTION: When reassembling the remote, be careful not to overtighten the screws, as this might damage the screws and the threads.



Operating the H30A

The Hegel H30A is a power amplifier that can be operated in either mono or stereo mode. Read more about the mono / stereo connection on page 14 and 15.

Power Button

The H30A amplifier can be switched on and off with the power button located in the middle of the front panel.


NOTE: When the H30A has been switched off, wait 30 seconds before powering it on again.

Control Input/Output

The H30A has a control/trigger input and output. If connected, a steady 5–12V signal will turn the outputs on. When the signal is 0V signal the output will be turned off. The control output allows you to daisy chain more H30's or other devices. The control connector uses a regular 3,5 mm jack plug. The control connectors will function with most trigger outputs (5–12V) from other manufacturers, but is only guaranteed to work with HEGEL control outputs.

NOTE: Connecting to a trigger output with more than 12V output may harm the amplifier and is not covered by the warranty.

Connections



Always power off the power amplifier before flipping any switches or connecting input/ output audio cables and the power cable.

Analog Inputs Right/Left

- XLR: Standard balanced analog input
- Input Selector
- · RCA: Standard analog input

Analog Inputs Mono

- XLR: Standard balanced analog input
- Input Selector
- · RCA: Standard analog input
- Stereo/Mono switch

NOTE: XLR Pin Configuration:

Pin 1 is Chassis Ground; Pin 2 is Positive

Phase; Pin 3 is Negative Phase

Speaker Outputs

- Speaker output right
- Speaker output mono:
 + right = mono, + left = + mono
- · Speaker output left

AC Power Connection

AC Power connector: 230V/115V/100V
 AC depending on country

Control input


5-12V control/trigger input (3,5mm jack)

Control output

12V control/trigger output (3,5mm jack)


Stereo Mode

When using the H30 as a stereo power amplifier, follow these instructions.



Mono Mode

When using the H30 as a mono power amplifier, follow these instructions.



Technical Specifications

P30A Preamplifier

Remote control Volume, source and mute 2 x XLR balanced, 3 x Inputs

> RCA unbalanced and Home Theatre inputs

Outputs 1 x XLR balanced and 2 x

RCA unbalanced outputs

3,5mm IR-direct jack, 3,5 Other connections

mm jack 12V trigger output

Signal to noise ratio More than 130 dB balanced

mode

Crosstalk Less than -100 dB Distortion Less than 0.005 % Intermodulation Less than 0.01%

(19kHz+20kHz)

Finish: Black

Dimensions/weight 9,6 cm x 43 cm x 30 cm

(HxWxD), 7,2 kg

3.8° x 17° x 12° Dimensions/weight US

(HxWxD), 15.9 lbs

H30A Power Amplifier

Min. load impedance

More than 1100 W in 8 Output power

> ohms (mono) 1 ohm load

Inputs RCA unbalanced and XLR

balanced

Speaker outputs One pair of heavy duty gold

plated terminals Input impedance

Balanced 20 kohm. unbalanced 10 kohm

Signal to noise ratio More than 100 dB

Crosstalk Less than -100 dB

Distortion Less than 0.003% at 100 W

in 8 ohm

Intermodulation Less than 0.01% (19 kHz +

20 kHz)

Damping factor More than 500 (moro) 2000 VA dual mono, Power supply

270,000 uF capacitors

Output stage 56 pcs 15 A 200 W high

speed, ultra-low distortion

bipolar transistors

Power consumption 120 W in idle mode.

30 W in ECO mode

Finish

Dimensions/weight 24 cm x 43 cm x 57.5 cm

(HxWxD), weight 47,4 kg

Dimensions/weight US 9.4" x 17" x 25.6"

(HxWxD), 104.5 lbs

General Information

Unpacking and Packing

When lifting the amplifier, be careful not to hold the knobs or connectors. Slide the bag off/on the device. When packing, make sure the bottom shock absorber is placed at the bottom of the original cardboard box. Place the amplifier into the shock absorber. Place the top shock absorber on top of the amplifier.

Placement and Cooling

The Hegel amplifier should be placed on a flat, hard surface for proper cooling. The amplifier must never be placed on a carpet or similar surface as this obstructs air circulation through the unit. For the same reason, the amplifier should have sufficient clearing above, and never be covered while in use.

The H30A power amplifier will automatically switch itself off if overheated. When it cools down the amplifier turns back on.

Cleaning

Fingerprints or stains on the front panel or top cover can be removed with a cloth moistened with warm water or a mild detergent suitable for cleaning mirrors and windows

Power

All electrical components should be turned off when not in use. This due to safety, because all electrical components can fail, and it is good for the environment. Leaving your product on all the time could also shorten the life expectancy of the product.

That being said, our products sound even better when they are warmed up, typically after about 15 minutes of listening at a moderate volume

Warning

Hegel products should only be opened or serviced by certified technicians. The devices contain electronic components that may cause severe electric shock. Work performed on Hegel products by unqualified personnel may cause serious damage or personal injury.

Opening of the product by non-authorized personnel will void the warranty.

The products must not be exposed to rain or moisture.

Warranty

All Hegel products come with a 2-year warranty against defective materials and workmanship. The warranty is limited to the region where it was originally purchased. There is no need for registering the warranty. The purchase receipt will work as a start date for the warranty.

In case you need assistance with your Hegel product, please contact your nearest dealer or distributor. These are listed on www.hegel.com. Our dealers are carefully chosen for their expertise and should be able to help you with any Hegel related issue. You can of course always reach us directly by sending an email to info@hegel.com or by contacting us on our social media pages.

For more information about the P30A and H30A, please visit www.hegel.com











